



## Service Part List\_ST1620T\_Version A

No.	Product Model#	Part Number	Description	Qty
2	ST1620T	5610237001	Tapping Screw	1
3	ST1620T	5610294001	Tapping Screw	2
4	ST1620T	3660124001	Spring	1
5	ST1620T	4870728002	Micro Switch	1
6	ST1620T	3129169002	Switch Support	1
7	ST1620T	3132757001	Switch Lever	1
8	ST1620T	3323135001	Top Switch Box Cover	1
9	ST1620T	3705464001	Limit Chute	2
10	ST1620T	5620334004	Hexagon Socket Screw	2
11	ST1620T	5620434003	Hexagon Socket Screw	1
12	ST1620T	2827594001	Front Handle Set	1
13	ST1620T	2828674002	Pothead Assembly	1
14	ST1620T	2828581002	Trigger Assembly	1
15	ST1620T	3660818001	Compression Spring	1
16	ST1620T	3131427001	Sliding Block	1
17	ST1620T	3127497001	Power Pack Button	1
18	ST1620T	3127498001	Power Pack Button	1
19	ST1620T	3660013003	Spring1	1
20	ST1620T	2828650003	Handle Assembly	1
21	ST1620T	2831727001	Electric Assembly	1
22	ST1620T	5680164001	Inner Hexagon Spanner	1
23	ST1620T	2828583001	Protective Cover Assembly	1
24	ST1620T	3132728001	Bottom Switch Box Cover	1
25	ST1620T	2828651002	Upper Housing Assembly	1
26	ST1620T	5630271001	Nut	1
27	ST1620T	2828646002	Lower Housing Assembly	1
201	ST1620T	2825434002	Connector ASSY	1